

ORCA 55L

2-8°C, 15-25°C, 20-24°C, -20°C



TEMPERATURE
CONTROLLED
PACKAGING



ORCA 55L is the latest addition to Intelsius' high performance range of solutions and provides over 120 hours of superior thermal protection for 2-8°C, 15-25°C, 20-24°C, -20°C and deep frozen temperature sensitive payloads.

ORCA 55L systems are designed to manage excursion risks, control costs and prioritise patient safety and can be used in 8 and 10 panel configurations to either increase payload or performance.

The ORCA range utilises our advanced Phase Change Materials (PCM) and Vacuum Insulation Panels creating unparalleled performance while reducing volumetric weight.

Features

- The high performance, extended duration that the ORCA provides ensures "life's most precious cargo" is always protected
- 2-8°C systems safe to place in a fridge when experiencing unplanned delays
- Can be packed in a fridge or ambient warehouse with 3D barcodes providing links direct to ORCA assembly guides
- Significant reductions in volumetric weight which provides a lower total cost of distribution
- Zero conditioning or bench time can be achieved for improved operational efficiency and removes the risk of cold shock
- Universal pack out makes the ORCA easy to use and reduces the risk of packing errors

For more information please contact Intelsius UK cs@intelsius.com

ORCA 55L

2-8°C, 15-25°C, 20-24°C, -20°C



TEMPERATURE
CONTROLLED
PACKAGING

Code	Product Name	External Dimensions	Payload Dimensions	Payload Volume	8 Panel Mass	10 Panel Mass	Volumetric Weight L/6
ORC068	ORCA 2-8°C 55L	796 x 432 x 432 mm 31.3 x 17.0 x 17.0 in	626 x 299 x 296 mm 24.6 x 11.7 x 11.6 in	55 L	25.0 kg 55.1 lbs	28.5 kg 62.7 lbs	24.8 kgvol ^c 54.5 lbsvol ^c
ORC069	ORCA 15-25°C 55L	796 x 432 x 432 mm 31.3 x 17.0 x 17.0 in	626 x 299 x 296 mm 24.6 x 11.7 x 11.6 in	55 L	27.8 kg 61.2 lbs	32.0 kg 70.3 lbs	24.8 kgvol ^c 54.5 lbsvol ^c
ORC070	ORCA -20°C 55L	796 x 432 x 432 mm 31.3 x 17.0 x 17.0 in	626 x 299 x 296 mm 24.6 x 11.7 x 11.6 in	55 L	28.5 kg 62.7 lbs	32.9 kg 72.3 lbs	24.8 kgvol ^c 54.5 lbsvol ^c
ORC071	ORCA 20-24°C 55L	796 x 432 x 432 mm 31.3 x 17.0 x 17.0 in	626 x 299 x 296 mm 24.6 x 11.7 x 11.6 in	55 L	24.5 kg 54.0 lbs	27.9 kg 61.3 lbs	24.8 kgvol ^c 54.5 lbsvol ^c

EUROPE: DGP Intelsius Ltd
1 Harrier Court, Airfield Business Park,
Elvington, York, YO41 4EA,
United Kingdom
t: +44 (0) 1904 607 390
f: +44 (0) 1904 607 391
cs@intelsius.com

AMERICAS: DGP Intelsius LLC
7696 Zionsville Road,
Indianapolis, IN 46268,
United States of America
t: +1 317 452 4006
f: +1 317 290 4621
americasorders@intelsius.com

ASIA: DGP Intelsius Sdn Bhd
Plot 11, Lorong Bemban 2, Estet
Perindustrian Bemban, 31000
Batu Gajah, Malaysia
t: +605 3666 399
f: +605 3669 399
compliance@intelsius.com



IRELAND: DGP Intelsius Teo
Unit 8, Ballyvourney Industrial Estate,
Ballyvourney, Co. Cork,
P12 A527, Ireland
t: +353 (0) 26 456 99
f: +353 (0) 26 456 98
salesireland@intelsius.com

INDIA: DGP Intelsius Cold Chain Pvt Ltd
2, Palak Pluto, Off Link Road,
Kanderpada - Dahisar (West),
Mumbai 400 068, Maharashtra, India
t: +91 22 6525 6621
f: +91 22 2892 3675
compliance@intelsius.com