

# LOGGER-INTEGRATED TEMPERATURE-CONTROLLED PACKAGING



TEMPERATURE  
CONTROLLED  
PACKAGING



**Intelcius have teamed up with data logger experts, Logmore, to offer a logger integrated, single use, temperature-controlled packaging solution.**

Solutions are supplied ready to use with the Logmore model 4 device integrated with our BioTherm, ORCA Single Use or PharmaTherm thermal packaging solutions. The external logger probe is routed through the packaging wall to minimise the risk of damage and a biodegradable protective mount protects the device in transit.

To use, simply scan the QR code to start your shipment, scan at waypoints for up-to-date data in transit and scan when it arrives at your destination. All data can be stored in ORCA Cloud, allowing you to efficiently monitor your payload temperature at critical stages in your cold chain.

## Features

- Scannable QR code for data access at your fingertips
- Easy setup and completion of shipments
- ORCA Cloud integration
- Dry ice, 2°C - 8°C, and 15°C - 25°C temperature ranges
- GMP Compliant logging device with NIST calibrated probe

## Benefits

- Payload temperature is displayed directly on the mobile phone after scanning the logger
- Payload temperature and packaging location uploaded to ORCA Cloud directly after scanning
- No APP installation required.
- Enables the remote release of goods without the need to open the packaging to remove the logger
- Devices do not have to be declared as dangerous goods with a lithium battery below the required size limit
- Devices settings maintained in the cloud reducing programming requirements
- Supplied fully integrated and ready to use increasing your operational efficiency

# LOGGER-INTEGRATED TEMPERATURE-CONTROLLED PACKAGING



TEMPERATURE  
CONTROLLED  
PACKAGING

## Choose Your Compatible Solution

We offer a range of single-use solutions that protect for your temperature-sensitive payloads. Using these high-performance solutions alongside Logmore devices allows costly temperature excursions to be avoided.

ORCA Single Use temperature-controlled parcel shippers combine advanced phase change materials (PCM) and vacuum insulated panel (VIP) technology to create a high-performance single-use cold chain packaging solution. ORCA Single Use ensures maximum performance while minimising volumetric weight, reducing your shipping costs.

PharmaTherm are insulated shipping systems designed to offer optimal thermal protection for pharmaceutical products with high-density EPS insulated shippers and water-based coolants utilised for efficient thermal protection.

BioTherm temperature-controlled packaging is designed to ensure full Category B UN3373 or Category A compliance, meeting IATA, ADR, and 49 CFR (DOT) transport regulations. BioTherm packaging provides the ideal solution when transporting temperature-sensitive specimens and has a pre-printed outer box, simplifying sample transport compliance.

### BioTherm



### PharmaTherm



### ORCA Single Use



	BioTherm	PharmaTherm	ORCA Single Use
Duration with PCM	48 - 96+	48 - 96+	72 - 96+
Duration with Dry ice	48 - 120+	48 - 120+	120+
Internal Volume	2L - 83L	2L - 84L	4L - 50L
Temperature Ranges	2-8°C, 15-25°C, Dry Ice	2-8°C, 15-25°C, Dry Ice	2-8°C, 15-25°C, -20°C, Dry Ice

**UNITED KINGDOM:** DGP Intelcius Ltd  
1 Harrier Court, Airfield Business Park,  
Elvington, York, YO41 4EA,  
United Kingdom  
t: +44 (0) 1904 607 390  
f: +44 (0) 1904 607 391  
cs@intelcius.com

**AMERICA:** DGP Intelcius LLC  
1399 Perry Rd, Suite 190,  
Plainfield, IN 46168,  
United States of America  
t: +1 317 452 4006  
f: +1 317 290 4621  
americasorders@intelcius.com

**MALAYSIA:** DGP Intelcius Sdn Bhd  
Plot 11, Lorong Bemban 2, Estet  
Perindustrian Bemban, 31000  
Batu Gajah, Malaysia  
t: +605 3666 399  
f: +605 3669 399  
compliance@intelcius.com

**GERMANY:** DGP Intelcius GmbH  
Eulerweg 11  
64291 Darmstadt  
Germany  
t: +49 6151 4936650  
f: +49 (0) 6151 4936651  
info@intelcius.de

**IRELAND:** DGP Intelcius Ireland Ltd.  
Unit 8, Coolcaslagh Industrial Estate,  
Coolcaslagh, Killarney  
Co. Kerry, V93 K006, Ireland  
t: +353 (0)64 668 61 71  
salesireland@intelcius.com

**INDIA:** DGP Intelcius Cold Chain Pvt. Ltd.  
Sun Srishti, C 10, Saki Vihar Road,  
Chandivali Powai, Mumbai - 400072  
Maharashtra - India  
+91 22 49746536  
compliance@intelcius.com